


# Talk Light

## Instructions for the Talk Light Timer

1. **Setting the hours for the Talk Light:** The timer comes preset to come on at 10:00 AM and turn off at 1:00 PM. You can adjust the hours based on your requirements. Locate the gray-segmented outer edge of the timer dial. You will see the gray segments pushed out between the hours of 10:00 AM to 1:00 PM. Each of these segments equals 15 minutes. To adjust the time you either push out the gray segments when the timer should be on or push in to turn the timer off during that time.
2. To set the current time, rotate the timer's dial clockwise until the gray arrowhead marked "set current time" on the face points to the current time of day. Note AM and PM is marked on the dial.
3. Set the switch at the side of the timer to **TIMER ON** position.
4. Plug the timer into an electrical outlet convenient to the Talk Light to be controlled.
5. Plug the Talk Light into the outlet on the bottom of the timer. The Talk Light will turn on and off at the times you have set.

**Note:** To override the timer and turn your Talk Light on, set the switch at the side of the timer to the **OUTLET ON** position. This will deactivate the timer's control of the lamp, but the timer's dial will still show the current time of day. To reactivate the timer's control of the lamp, set the timer's switch to **TIMER ON**. In case of a power failure, reset the time of day as explained in step 2.



**DO NOT PLUG OTHER DEVICES INTO THE TALK LIGHT TIMER, AS IT WILL BECOME OVER LOADED.**